


NEWAGE POSTER CLAMP




•Turn the endcaps on the edge of the clamp profile.



•Open the profile and slide the poster, through the profile.



•Close the profile and the endcaps.



•Adjust the position of the hangers.

