




WRITE ON A BOARD



- Pull out the iron legs of the Write on A Board to opposite directions and open your A Board up by putting the scissors on two sides in straight position.

- Suitable for writing with boardmarker & waterbase chalkpen.



NOTE:
• Optional colours are available.